

Cover Butler

Under Spa Bracket Installation



You should have the following parts to attach the “Mounting Blocks” to the under spa brackets versus the spa skirt. 8 Screws, 8 Self Locking Nuts, 2 Mounting Block, and 2 Plates (Figure A).

1. Insert the screws from the bottom up through the plate and then through the corners of the mounting plate. Attach a locking nut on all 4 screws.
2. Slide the brackets under the spa on the backside of the spa.



3. Slide the **LONG SIDE** of each of the two bottom Corner Pieces into the Mounting Blocks. Remember, **EACH CORNER PIECE MUST HAVE THE PRE-DRILLED HOLES FACING UP.**

From here, refer to the installation manual that you received with the lifter starting at #3.